



ENERG

енергия · ενεργεια



Bosch

7736504486



Two icons representing sound power levels. The top icon shows a house with a speaker and the text "15 dB". The bottom icon shows a house with a speaker and the text "0 dB".

Two columns of energy consumption icons. The left column shows a blue square with a minus sign, the number "4404", and another blue square with a minus sign, followed by the text "kWh/annum". The right column shows a blue square with a minus sign, another blue square with a minus sign, and a light blue square with a minus sign, followed by the text "GJ/annum". Below these is a map of Europe with various shades of blue.